

Quick Start Guide



- Press and hold the Power Button for 7 seconds. You don't need to use the plug or cord—they're used to recharge the device.
- 2. Wait about 30 seconds for the device to move through several screens.
- 3. Once "Sprint" is displayed on the screen, press the power button to display the Wi-Fi name.
- 4. Press the power button again to display the hotspot's password.
- 5. In the Wi-Fi settings of your computer or device, choose the hotspot name and enter the hotspot password.

